

TC460N

Ford 460 Timing Cover Instructions



TC460N



DT460

INSTALLATION INSTRUCTIONS

1) ON 460 FORD WITH DIPSTICK TUBE IN FRONT COVER AND FUEL PUMP, INSTALL ORIGINAL DIPSTICK TUBE IN DIPSTICK HOLE. IF NEW DIPSTICK TUBE IS NEEDED PURCHASE ENGINEQUEST PART NUMBER EQ-DT460. (ORIGINAL FORD PART NUMBER C8SZ-6754-A). NEW DIPSTICK TUBE MUST BE INSTALLED SO THE TOP OF THE TUBE IS 13/16" ABOVE CASTING (HARDWARE KIT IS NOT NEEDED).

2) ON 460 FORD WITH NO DIPSTICK IN FRONT COVER BUT HAS A FUEL PUMP, INSTALL DIPSTICK PLUG IN DIPSTICK TUBE HOLE. INSERT PLUG BY HAND FIRST, LIGHTLY TAP PLUG IN PLACE WITH MALLETT MAKING SURE PLUG IS FULLY SEATED WHEN FINISHED.

3) ON 460 FORD FUEL INJECTION WITH NO DIPSTICK IN COVER AND NO FUEL PUMP, INSTALL DIPSTICK PLUG IN DIPSTICK TUBE HOLE. INSERT PLUG BY HAND FIRST, LIGHTLY TAP PLUG WITH MALLETT MAKING SURE PLUG IS FULLY SEATED WHEN FINISHED. INSTALL FUEL PUMP BLOCK-OFF PLATE AND GASKET OVER FUEL PUMP MOUNTING.

4) ON 460 FORD FUEL INJECTION '91 AND LATER WITH NO DIPSTICK IN COVER AND NO FUEL PUMP, INSTALL DIPSTICK PLUG IN DIPSTICK TUBE HOLE. INSERT PLUG BY HAND FIRST, LIGHTLY TAP PLUG WITH MALLETT MAKING SURE PLUG IS FULLY SEATED WHEN FINISHED. INSTALL SPECIAL 5/16TH STUDS WITH LOCKTITE IN FRONT COVER OIL PAN BOLT HOLES. INSTALL FUEL PUMP BLOCK-OFF PLATE AND GASKET OVER FUEL PUMP MOUNTING.